


PÖÖRLEV PESUHARI WB 130

Alati liikumises: vahetatavate harjastega pöörlev pesuhari siledade pindade, nt värvitud, klaas- või plastpindade puhastamiseks. Tänu integreeritud vabastushoovale on tarvikute vahetamine kiire.



Tellimuse nr.

2.644-286.0

Tehnilised andmed

EAN-kood		4054278862682
Värvus		Must
Kaal	kg	0,4
Kaal, sh pakend	kg	0,5
Mõõdud (pikkus × laius × kõrgus)	mm	305 × 156 × 137



Pöörlev harjapea

- Õrnatoimeline ja tõhus puhastus
- Mugav ja käepärane puhastus.

Lisatarviku vahetamine vabastushoovaga

- Kiirem ja lihtsam tarviku vahetus ilma mustusega kokku puutumata.
- Hoidke oma käed alati puhtad.
- Valige iga puhastusülesande jaoks õiged harjased.


Puhastusvahendi pinnale kandmine harjaga ühendatud survepesuri abil

- Mustuse parem leotamine ja tõhus puhastamine.

KOKKUSOBIVAD MASINAD

- G 7.180
- K 2
- K 2 Classic
- K 2 Classic Car
- K 2 Classic Home
- K 2 Compact
- K 2 Compact Car & Home
- K 2 Power Control
- K 2 Power Control Car
- K 2 Power Control Home
- K 2 Premium FJ
- K 2 Premium FJ Home BB
- K 2 Premium Horizontal VPS
- K 2 Premium Power Control
- K 2 Universal Edition
- K 2 Universal Edition Car
- K 2 Universal Edition OJ
- K 2 aku komplektiga
- K 3
- K 3 Car
- K 3 Car & Home
- K 3 Classic
- K 3 Classic Car
- K 3 Classic Home
- K 3 FJ BB
- K 3 FJ Home BB
- K 3 Horizontal Plus
- K 3 Horizontal Plus Home
- K 3 Power Control
- K 3 Power Control Car
- K 3 Power Control Car & Home
- K 3 Power Control Home
- K 3 Premium Power Control
- K 3 Premium Power Control Home
- K 4 Classic
- K 4 Classic Car
- K 4 Classic Home
- K 4 Comfort Premium
- K 4 Comfort Premium Home & eco!Booster
- K 4 Comfort Premium Veranda
- K 4 Compact
- K 4 Compact Home
- K 4 FJ
- K 4 FJ Home
- K 4 Power Control Flex
- K 4 Power Control Flex Home
- K 4 Power Control Flex Home & Wood
- K 4 Power Control Flex eco!Booster
- K 4 Premium Power Control Flex
- K 4 Premium Power Control Flex Home
- K 4 Premium Power Control Home
- K 4 WCM
- K 4 WCM Plus
- K 4 WCM Premium Home
- K 5 Basic
- K 5 Classic
- K 5 Classic Car & Home
- K 5 Classic Home
- K 5 Comfort Premium
- K 5 Comfort Premium Connect
- K 5 Comfort Premium Connect Home
- K 5 Comfort Premium Garden
- K 5 Comfort Premium Home Wood
- K 5 Comfort Premium Home&eco!Booster
- K 5 Compact
- K 5 Compact FJ 6 Set
- K 5 Compact Home
- K 5 FJ
- K 5 FJ Home
- K 5 Power Control Flex
- K 5 Power Control Flex Home
- K 5 Power Control Flex Home eco!booster
- K 5 Power Control Flex Home&Brush Anniversary Edition
- K 5 Power Control Flex Stairs
- K 5 Power Control Flex WKS
- K 5 Premium Power Control Flex
- K 5 Premium Power Control Flex Black
- K 5 Premium Power Control Flex Home
- K 5 Premium Power Control Flex Suction
- K 5 Premium Smart Control Flex
- K 5 Premium Smart Control Flex Home
- K 5 Premium Smart Control Flex eco!B
- K 5 Smart Control Flex
- K 5 WCM Premium
- K 5 WCM Premium Home
- K 5 WCM V1
- K 6 Comfort Premium
- K 6 Special
- K 7 Comfort Premium
- K 7 Comfort Premium Connect
- K 7 Comfort Premium Connect Car&Home
- K 7 Comfort Premium Connect Facade
- K 7 Comfort Premium Home Wood
- K 7 Comfort Premium Home&eco!Booster
- K 7 Compact
- K 7 Compact Home *EU
- K 7 Power Control Flex eco!Booster
- K 7 Power Flex
- K 7 Power Flex Home
- K 7 Premium Power Flex
- K 7 Premium Power Flex Home
- K 7 Premium Smart Control Anti-Twist Flex
- K 7 Premium Smart Control Flex
- K 7 Premium Smart Control Flex Home
- K 7 Premium Smart Control Flex Home FJ
- K 7 Premium Smart Control Flex eco!B
- K 7 Smart Control Flex
- K 7 Smart Control Flex Home
- K 7 Smart Control Flex Home T5 Black
- K 7 Smart Control Flex WSK
- K 7 Smart Control Home
- K 7 WCM
- K 7 WCM Car&Home
- K 7 WCM FJ
- K 7 WCM FJ Home
- K 7 WCM Premium

LISATARVIKUD PÖÖRLEV PESUHARI WB 130 2.644-286.0



		Tellimuse nr.	Kirjeldus	
HARJAD				
Vahetatavad universaalharjased mudelile WB 130	1	2.644-289.0	Ideaalne kõikide siledetele pindadele nagu värvitud, klaas- või plastpindade puhastamiseks: vahetatavad universaalharjased Universal pöörlevale pesuharjale WB 130.	<input type="checkbox"/>
Vahetatavad universaalharjased mudelile WB 130 Car & Bike	2	2.644-290.0	Ideaalne autode ja mootorrataste puhastamiseks: vahetatavad mikrokiust auto- ja rattapesuharjased Car & Bike pöörlevale pesuharjale WB 130.	<input type="checkbox"/>
Vahetatavad universaalharjased mudelile WB 130 Home & Garden	3	2.644-291.0	Kodumajapidamises olevate tugevate pindade põhjalikuks puhastamiseks: vahetatavad harjased Home & Garden pöörlevale pesuharjale WB 130.	<input type="checkbox"/>
Aiavooliku ühenduse adapter	4	2.640-732.0	Adapter aiavoolikute ühendamiseks - sobib kõikide Kärcheri harjade kinnitamiseks aiavoolikute külge, millel on kiirkinnitussüsteem.	<input type="checkbox"/>

Tarnitakse koos seadmega
 Saadaval olevad lisatarvikud.
 Pesuaine.